



BC10345 RMC Maintenance and repair kit teak black
BC10466 RMC Maintenance and repair kit teak grey

Reparation

Due to intensive use of the furniture, it is always possible that minor damage occurs to the furniture. We have therefore put together a maintenance and repair kit with which you can easily repair minor damage yourself. Below you can read step by step how to do the repair yourself.

RINSE WITH WATER + APPLY RMC EXTERIOR WOOD CLEANER

The product removes grease, green deposits and dirt. Both new, greyed and already treated wood always has to be cleaned with RMC Exterior Wood Cleaner before an application with oil is done.



1l = 15 m²

INSTRUCTIONS FOR USE:

- Moisten the surface with the garden hose. NEVER use a high-pressure cleaner on wooden furniture.
- Apply RMC Exterior Wood Cleaner with a hard hand brush.
- Scrub the area to be treated in the lengthwise direction of the wood until it is clean. The product will foam up. In case of persistent deposits repeat the treatment if necessary.
- Rinse thoroughly with water until all foam has disappeared.
- Allow the surface to dry thoroughly (± 24 hrs, as the surface must look and feel evenly dry).



This product can cause irritation to the eyes, so make sure you have sufficient protection.

If you would treat your garden furniture on a terrace, you should rinse off the wood cleaner afterwards. Make sure that the product does not come into contact with the water of a fish pond.

IF REQUIRED: RMC SUNPRIMER BLACK or GREY.

RMC sunprimer HWP is a water-based primer and should only be used for touching up damage of which the raw wood is visible again.



INSTRUCTIONS FOR USE:

- Stir RMC Sunprimer HWP well.
- Apply a small quantity of RMC Sunprimer HWP uniformly with a fine brush or applicator (depending on the size of the surface to be treated).
- Allow to dry for at least 2 hours.

RMC HYBRID WOOD PROTECTOR.

It is important to treat your outdoor wood against various weather influences. RMC Hybrid Wood Protector can help you with that. Hybrid Wood Protector is the ultimate wood protection for your wooden garden furniture! Our exterior wood oil protects and colours all exterior wood in one single layer. The wood oil protects all types of wood. The easy application makes this oil an extremely user-friendly product!



1l = 30 m²l

INSTRUCTIONS FOR USE:

- Mix the oil well before use.
- After drying, apply a layer of RMC Hybrid Wood Protector with a sponge. Be careful when dosing and start with a small amount of oil.
- Rub this onto the surface so that there are no oil marks. Allow to soak in for about 5 minutes.
- Go over the surface with a cotton cloth to remove excess oil.
- Allow to dry for 24 hours. Complete curing is achieved after 7 days.



Hybrid Wood Protector is a product based on linseed oil. After using this product **ALWAYS** immerse your sponge and rag in water for 24 hours before discarding.



Daily maintenance

RMC SOAP.

The RMC soap is used for regular cleaning of the furniture. This soap thoroughly removes all dirt and grease without building up a layer. It preserves the matt natural look of the wood.



10 ml/1 l water

INSTRUCTIONS FOR USE:

- Pour the soap into a bucket of water according to the specified dosage.
- Fill a second bucket with water only for rinsing the cloth.
- Remove all dirt from the surface with a lint-free cotton cloth.
- Do not allow water to stand on the treated surface.
- Drying time: ± 15 minutes